

A8682
Fuse holder

F02

87
20A

4 X8582

5 X60681

U_HR<2
0.75
RT/GE

1



A460
Digital diesel electronics

67

31

68

X2411

A_PULS
0.35
GE/GN

M_OLN
0.35
BR/GN

S_OLD
0.35
SW/GR

3

2

X2473

1

X2083

B6120
Oil-level sensor

B2008
Oil pressure switch

not with N47D16U1 engine