



Z2a
Power distribution box, rear
2) LIN power distribution box

F217
F224 - F230
F233 - F237
F242 - F246

30B_1

F212 - F216
F218 - F220
F247 - F252
F253 - F260
F265 - F267

30B_2

F261 - F264
F268 - F274
F281 - F286
F291 - F296

30F_1

F238 - F240
F276 - F280

30F_2

F287 - F290

15N

F203 - F211
F221 - F223

HHS

F231
F232