


with automatic engine start-stop function and without DC/DC converter

without automatic engine start-stop function or with automatic engine start-stop function and DC/DC converter

up to 2012\_06

from 2012\_07



with automatic engine start-stop function and without DC/DC converter

without automatic engine start-stop function or with automatic engine start-stop function and DC/DC converter

