


30 X10015



U\_GETRPOS  
0.5  
GN

5 X8532



S8532

Gear position switch  
0) Low (Off)  
1) High (On)

1 3 4 2 X8532

S\_GL1  
0.5  
OR

S\_GL3  
0.5  
VI


S\_GL4  
0.5  
GE

S\_GL2  
0.5  
BL/SW

X8589

X8600

36 37 9 8



A8600

AGS transmission control unit

L1

L3

L4

L2

31 31 31 31