







A7000
AGS transmission control unit




A1
General module
3) Load cutout



A3
Light module



S224
Stepronic switch
0) OFF
1) Manual gearshift
2) Upshift
3) Downshift



S227
Selector lever position switch



E82
Gear indicator light

