

A41a  
Fuse holder, front

5 X11005

30<30  
1.5  
RT/GN

X15006

K\_CAN\_SL  
0.5  
GE


X15005

K\_CAN\_SH  
0.5  
SW

1 X13765

7

6 X1527



A11a  
Heating/air conditioning system

2 X13765

31  
1.5  
BR

25 X1527

31  
0.5  
BR

X875

X13784