



A72
Steering column
switch cluster
3) Direction indicator/
low beam switch

A3
Light module

S8
Light switch unit
1) Light switch
8) Lighting for light
switch unit

A16760
Body-gateway module

A3
Light module

E7
Left headlight
4) Low beam headlight
5) High beam head-
light

E8
Right headlight
4) Low beam headlight
5) High beam head-
light