



**A72**  
Steering column  
switch cluster  
3) Direction indicator/  
low beam switch

**A3**  
Light module

**S8**  
Light switch unit  
1) Light switch  
8) Lighting for light  
switch unit

**A16760**  
Body-gateway module

**A3**  
Light module

**E7**  
Left headlight  
4) Low beam headlight  
5) High beam head-  
light

**E8**  
Right headlight  
4) Low beam headlight  
5) High beam head-  
light