



Z2a  
Power distribution box, rear  
1) LIN power distribution box

Z44  
Front right power distribution box

Z43  
Front left power distribution box

Z3  
Fuse box

A258  
Body Domain Controller

A361

A258\*5B  
SV\_LIN  
0.35  
GN/VI

A258\*3B  
15\_1  
0.35  
GN

31  
0.35  
BR

Z10\*12B

A361\*1B

30<501  
35.0  
RT

Z2\*10B

30B\_EIN  
0.5  
GE/BL

30B\_AUS  
0.5  
GE/BR

30B\_EIN  
0.5  
BL/VI

30B\_AUS  
0.5  
BL/GE

