



S69a
Centre console control panel
13) START-STOP button
14) MSA button




- 31_SSP1**
0.35
BL/GN
- SSP1**
0.35
GN
- 31_SSP2**
0.35
GE/GN
- SSP2**
0.35
WS/BL
- LED_SSP**
0.35
WS
- K_LIN_21**
0.35
VI/WS



A258
Body Domain Controller




- S_BLS**
0.35
BL/RT




A91
Dynamic stability control (DSC)

- SW/GE** B57 engine
- WS** B58 engine
- RT/WS** N63/S63 engine




M92
Starter



- B+**
85.0
RT
- B+**
59.0
SW

- Z4*1B** with dual storage system
- Z4*4B** without dual storage system

Z4
Front power distribution box




- Z3*3B** with dual storage system
- Z3*2B** without dual storage system

Z3
Fuse box

- B+**
50.0
RT

G1
Battery



- X6402**