

A41a

Fuse holder, front

5 X11005

30<30
1.5
RT/GN

X15006

K_CAN_SL
0.5
GE

X15005

K_CAN_SH
0.5
SW

1 X13765


31

7

6 X1527

A11a

Heating/air conditioning system



2 X13765

31
1.5
BR

X13784

25 X1527

31
0.5
BR

X875