








Z42  
Power distribution box




B6120  
Oil-level sensor



B268  
Engine-oil pressure sensor



Y84  
Oil pressure control valve



Z42  
Power distribution box

