




Z2
Fuse holder, rear



1 Z2*9B



A98
Fuel pump control (EKPS)



2 A98*1B


31
2.5
BR

MEKP+
2.5
RT/GN

MEKP-
2.5
BR

4 X94*1B

M14
Electric fuel pump



Z10*12B