



A12
Airbag diagnostic
module

45 46 47 48 X1081

ITSAL+
0.5
GE

ITSAL--
0.5
BL/GE

ITSAR+
0.5
WS

ITSAR--
0.5
BL/WS

1 2 X1966

1 2 X1965

G18
Generator, pas-
senger airbag
head area (ITS)

G17
Generator, driver
airbag head area
(ITS)

