



Diesel Petrol engine

X328*1V

B+ 0.75 VI

G1*2B
G1 Battery

A11
Crash safety module

SBK+ 0.35 SW/GN SBK- 0.35 WS

B73
Gas generator, safety battery terminal

M_LIN 0.35 GR/GN

M_LIN 0.35 GR/GN

A46*1B
A460 Digital diesel electronics

A46*1B
A46 Digital Motor Electronics

G6*2B
G6 Auxiliary battery

B+ 50.0 RT

X593a
Transfer point 2

B+ 35.0 RT

B+ 85.0 RT

B+ 85.0 RT

A258
Body Domain Controller

R6
CAN terminator 6

F508
Fuse box

F300
Fuse box auxiliary battery

Z4
Front power distribution box
1) Capacitor box
2) Jump start terminal point

PT_CAN2H 0.35 PT_CAN2L 0.35

WS/GE	WS/BL
WS/GR	BL/GR

F30
60A

F30
60A

F30
60A

A460
Digital diesel electronics

A46
Digital Motor Electronics

30F<4 0.35 RT/GE

15WUP 0.35 GN

N7*2B

N7*1B

N7*1B

B+ 42.0 SW

B+ 59.0 SW

Diesel Petrol engine

G2*1B
G2 Alternator

M92*2B
M92 Starter