






S2  
Ignition switch  
0) OFF  
1) Radio position  
2) Ignition  
3) Start



L1  
EWS toroidal coil



A6000  
DME control unit



M6510a  
Starter