



A117a
Eject box

B402
Microphone, left

W18
Bluetooth aerial

A267a
AUX-IN connection
1) USB connection

13 X4545

3 X3564

2 X9331

X4373

21 X16977

1 X14080

1 X18807

4 X17181

4 X14118

4 X17183

1 X17182

CRADLE_O
0.35
BL

MIC+
0.35
GE

MIC-
0.35
SW

31
0.35
BR

ANT_BT
0.09
WS

AUX_GND
0.35
VI

AUX_NF_L
0.35
WS/RT

AUX_NF_R
0.35
WS/GN

USB_DAT+
0.14
BL

USB_VCC
0.14
OR

USB_DAT-
0.14
GN

USB_GND
0.14
BR

U400e
ULF-SBX-H