





A568

Gear selector switch (GWS)


3) START-STOP button



A568*1B



X1872*1B



A528*5B

A528

Basic central platform (BCP)