



Left-hand drive

Right-hand drive

A376
Ethernet switch (ENS)

A528
Basic central platform (BCP)

A545
BMW Touch Command at the rear left (BMTHL)

A546
BMW Touch Command at the rear right (BMTHR)

A18
Seat module, rear driver's side (SMFAH)

E167
Rear driver's side backrest heating

E473
Seat cushion heating, driver's side rear