



A568

Gear selector switch (GWS)
 3) START-STOP button

A568*1B

X246*1B

A528*5B

A528

Basic central platform (BCP)