




A568
 Gear selector switch (GWS)
 3) START-STOP button



A568*1B



X1872*1B



A528
 Basic central platform (BCP)

