




A568

Gear selector switch (GWS)


3) START-STOP button



A568*1B

X1872*1B

A528*5B



A528

Basic central platform (BCP)