
Z44
Front right power distribution box
F67
F68
F60
30B<67
0.35
RT/GN
30B<68
0.35
RT/GN
30B<60
0.35
RT/BL
30B<60
0.35
RT/BL
S19*1B
S19
Seat switch cluster on driver's door
S23*1B
S23
Seat switch cluster on passenger's door
S27*1B
S27
Seat switch cluster, rear driver's side door
S28*1B
S28
Seat switch cluster, rear passenger's side door
31
0.35
BR
FAT_LIN
0.35
WS/BL
BFT_LIN
0.35
WS/BL
FAT_LIN
0.35
WS/GN
BFT_LIN
0.35
WS/GN
X117*1V
X140*1V
X119*1V
X550*1V
X120*1V
X120*1V
X1323*1V
X315*1V
X315*1V
X1324*1V
A258
Body Domain Controller
A258*8B
K_CAN2_H
0.35
GE/BR
K_CAN2_L
0.35
GE/RT
R2*1B
R2a
CAN terminator 2
Z10*46B
BR
BR/SW
S13
Seat adjustment switch cluster, rear passenger's side
S13*1B
AD4
0.35
GE/BL
GND
0.35
BL/GN
X200*1B
X1320*1B
A348
Rear right seat inflator module
A348*1B
Z2a
Power distribution box, rear
F263
Z2*5B
30B<263
0.75
RT/BL
S11
Seat adjustment switch cluster, rear driver's side
S11*1B
X1319*1B
A351
Rear left seat inflator module
A351*1B
without Captain's Chair
F65
30B<65
0.35
RT
S154
Seat adjustment switch block, Front passenger side
S154*1B
A350
Front right seat inflator module
A350*1B
F64
30B<64
0.35
RT
S153
Seat adjustment switch block, driver's side
S153*1B
A349
Front left seat inflator module
A349*1B
LO_CAN_H
0.35
BL/RT
LO_CAN_L
0.35
BL/BR
LO_CAN_H
0.35
BL/RT
LO_CAN_L
0.35
BL/BR
LO_CAN_H
0.35
BL/RT
LO_CAN_L
0.35
BL/BR
LO_CAN_H
0.35
GE/BR
LO_CAN_L
0.35
GE/RT
LO_CAN_H
0.35
GE/BR
LO_CAN_L
0.35
GE/RT
X1320*1B
X1319*1B
X249*1V
X249*1V
X12*1B
X642*1V
X642*1V
X14*1B
X641*1V
P_PWM_HR
0.35
RT
GND
0.35
WS
P_PWM_HL
0.35
RT
P_PWM_VR
0.35
RT
P_PWM_VL
0.35
RT
W9110.2
M4b
Seat pneumatics module pump, rear right
M82b
Seat pneumatics module pump, rear left
M216
Seat pneumatics module pump, front right
M215
Seat pneumatics module pump, front left