
Z2
Fuse carrier, rear
F140
F134
from 2012_04
up to 2012_03
from 2012_04
up to 2012_03
Luggage compartment light
Luggage compartment light 2
without Automatic Soft Close system
with Automatic Soft Close system
Boot tailgate lock
Z1
Junction box
Glove compartment light
Mirrors module
Roof functions module, Basic variant
Roof functions module, High variant
Roof function centre
Z1 Map reading light, left
Z2 Map reading light, right
Z3 Interior light
Roof functions module, High variant
Roof functions module, Basic variant
Mirrors module
Mirror light, front left
Mirror light, front right
Mirror switch, front left
Mirror switch, front right
with reading light
without reading light
Mirror light, rear left
Z1 Interior light
Z2 Locator lighting button, interior
Z3 Interior light
Z5 Interior light button
Mirror light, rear right
Z1 Interior light
Z2 Locator lighting button, interior
Z3 Interior light
Z5 Interior light button
Z6
Footwell module
Passenger's door entrance light
Driver's door entrance light
Entry light, passenger's side, rear
Entry light, driver's side, rear
Entrance light, driver's door
Entrance light, passenger's door
Courtesy lighting, driver's side, rear
Courtesy lighting, passenger's side, rear
Footwell light, front left
Footwell light, front right
Rear left footwell light
Rear right footwell light
Z1
Junction box
left-hand drive
right-hand drive