
30
F72
R
F7
30
F73
30<72
R<7
30<73
K3
Unloader relay terminal R
31L<7
R<E
A3
Light module
58G
A2
Instrument cluster
K--BUS
TAA
without IKE
A63
Integrated electronic control unit (IKE)
I--BUS
TAA
with IKE
TAA
H38
Transceiver/charging electronics
TELM
Motorola
U407
Basic interface, telephone
1) with hands--free facility
TELM
Siemens
TELM
I01029
Multifunction steering wheel
1) Steering wheel electronics, left side
I01029
Multifunction steering wheel
2) Steering wheel electronics, right side
I01030
Coil spring
K--BUS
A197
Video module
VM+
VM--
Not used
not USA
USA
A196
On--board monitor
TAPEL+
TAPEL--
TAPER+
TAPER--
N9
Radio
RADLV+
RADLV--
RADRV+
RADRV--
TAA
RADLH+
RADLH--
RADRH+
RADRH--
F72
30<72
ANT
A18
Amplifier
31E<RAD
MTVL+
MTVL--
HLV+
HLV--
TLV+
TLV--
H41
Left front speaker
TELNF+
TELNF--
H59
Left front high range speaker
H55
Left front mid--range speaker
TRV+
TRV--
MTRV+
MTRV--
HRV+
HRV--
H50
Right front high range speaker
H54
Right front mid--range speaker
H44
Right front speaker
TELNF+
TELNF--
TLH+
TLH--
TRH+
TRH--
MTHL+
MTHL--
MTHR+
MTHR--
H43
Right medium--range/high--range speaker
H42
Left medium--range/high--range speaker
H52
Rear right woofer
H57
Rear left woofer
TELNF+
TELNF--
Siemens
Motorola
with SES
31E<RAD
U407
Basic interface, telephone
1) with hands--free facility
H38
Transceiver/charging electronics
U422
Voice input