
F51
F32
A3
Light module
A2
Instrument cluster
F51
H38
Transceiver/charging electronics
A112
Navigation control unit
N8
Antenna amplifier
30<51
R<32
58G
K--BUS
30<51
N22
CD changer
NAVNF31
NAVNF
NAV--BUS
ANT
K--BUS
K--BUS
31
CD_NFL+
CD_NFL--
CD_NFR+
CD_NFR--
CD_NF31
MUTE
ANT
N9
Radio
F51
30<51
VL+
VL--
VR+
VR--
A96
Convertible soft top control unit
V_OFF
HL+
HL--
HR+
HR--
ANT
A18
Amplifier
MLV+
MLV--
HLV+
HLV--
MRV+
MRV--
HRV+
HRV--
H42
Left medium--range/high--range speaker
H43
Right medium--range/high--range speaker
MLH+
MLH--
MRH+
MRH--
H45
Right rear speaker
H46
Left rear speaker
TTHL+
TTHL--
TTHR+
TTHR--
TLV+
TLV--
TRV+
TRV--
H51
Woofer, front right
H52
Rear right woofer
H58
Woofer, front left
H57
Rear left woofer
31
31