
J519
Vehicle central platform (BCP)
F1
Power distribution box in the centre
F2
Power distribution box, front
J533
Data bus for interior lighting, rear, front right
J534
Data bus for interior lighting, rear, front left
J533
Data bus for interior lighting, rear, rear right
J534
Data bus for interior lighting, rear, rear left
J519
Vehicle central platform (BCP)
J386
Driver's door control unit
J387
Front passenger door control unit
J388
Rear left door control unit
J389
Rear right door control unit
J533
Data bus for interior lighting, rear, front right
J534
Data bus for interior lighting, rear, front left
J533
Data bus for interior lighting, rear, rear right
J534
Data bus for interior lighting, rear, rear left
J519
Vehicle central platform (BCP)