
with ARS
B39
Front left level sensor
B35
Front right level sensor
B11
Rear left level sensor
B37
Rear right level sensor
B173
Vertical-acceleration sensor, front left
B172
Vertical-acceleration sensor, front right
B175
Vertical acceleration sensor, rear left
B174
Vertical acceleration sensor, rear right
A333
Vertical dynamics platform
Y44
Valve coil, front left
1) Rebound stage
Y45
Valve coil, front right
1) Rebound stage
Y46
Valve coil, rear left
1) Rebound stage
Y47
Valve coil, rear right
1) Rebound stage