
F84 Seat heating switch, rear driver's side
S07 Seat heating switch, rear passenger's side
J07 Keyless immobilizer control electronics
J409 Seat heating electronics, driver's side rear
J410 Seat heating electronics, passenger's side rear
J409 Driver's seat heating electronics
J410 Front passenger seat heating electronics
J409 Driver's touch control box
J485 Steering column switch cluster
J412 Remote control receiver, luggage compartment
J527 Roof function centre (FZE)
J1 Siren with tilt alarm sensor
J60 Electrochromic interior mirror
J31 Interior light, rear
J533 Wiper module
J519 Left-hand drive
J519 Right-hand drive
E110 Rain-light-solar-condensation sensor
J80 Steering column adjustment
J250 Evaluation electronics, contact-free tailgate opening
J932 Sun sensor, rear window
J533 Blower motor
M14 Fresh air/recirculated air flap motor
Diesel engine
J965 Automatic rear air-conditioning operating facility
J817 Interior temperature sensor
J235 Touch control box, front passenger
J486a Touch control box, instrument panel
J486 Driver's touch control box
J151 Low pressure refrigerant pressure/temperature sensor
J151 High pressure refrigerant pressure/temperature sensor
V156 Electric auxiliary heater
V154 Expansion valve of heat pump circuit
V192 Electric A/C compressor
V192 Electric A/C compressor
PHEV
BEV
PHEV/BEV
J401 Coolant pump 3
V50 Coolant changeover valve
V54 Coolant changeover valve 3
V51 Coolant changeover valve 2
V55 Independent/auxiliary heater
J401 Coolant pump 3
J2 Power distribution box, rear
J519 Left-hand drive
J519 Right-hand drive
J519 Left-hand drive
J519 Right-hand drive
J519 Left-hand drive
J519 Right-hand drive