
F34 Front right power distribution box
F35 Front left power distribution box
F36 Front right power distribution box
G20 Front left power distribution box
K10 Front control panel (ECP)
K11 Front control unit, passenger side (ECUpass)
K12 Rear control unit, rear passenger side (ECUpsg)
K13 Front control unit, driver's door (ECUdrg)
K14 Rear control unit, rear driver's side (ECUdrs)
E1 Lighting, decorative strip, front passenger door
E2 Front passenger door, tweeter lighting
E3 Front passenger door handle light, front passenger door
E4 Lighting, mid-range speaker, front passenger door
E5 Front pocket lighting, front pas-senger door
E6 Lighting, decorative strip, door, passenger's side, rear
E7 Rear door handle light, rear passenger door
E8 Lighting, mid-range speaker, rear passenger door
E9 Rear pocket lighting for the door on passenger's side rear
E10 Headlight, front right
E11 Lighting, front passenger seat footwell
E12 Lighting, decorative strip, door
E13 Lighting, backrest, front pas-senger
E14 Driver's door, tweeter lighting
E15 Lighting, mid-range speaker, driver's door
E16 Rear door handle light, driver's door
E17 Front pocket lighting, driver's door
E18 Lighting, decorative strip, door, driver's side, rear
E19 Rear door handle light, rear of driver's door
E20 Lighting, mid-range speaker, rear of driver's door
E21 Rear pocket lighting for the door on driver's side rear
E22 Headlight, front left
E23 Lighting, 2 driver's seat footwell
E24 Lighting, backrest, driver's seat